AKAI SENSING TAPE



(A) Cut sensing tape approximately 1 inch. If the sensing tape is too long or too short functional failure may occur.

(B) The sensing tape should precisely be centered on the shiny side or the dull side of the tape in use.

(C) If the sensing tape is dirty, the proper reverse operation of the tape will not be made.